




INFINITY 26i and HD50i

SERVICE MANUAL



Infinity High Capacity Continuous Flow Gas Hot Water System

The Rinnai Infinity 26i and Heavy Duty 50i water heater, when correctly installed, comply with the requirements of the United Kingdom Water Regulations / Byelaws (Scotland). These Products can be found listed in the Water Fittings and Materials Directory.



The Rinnai Infinity 26i water heater is CE Marked for UK and Ireland as allowed by Technigas of Belgium.
Certificate number E0716/5360
ID number 0461BO0739
Date of Issue 28 July 2003

Quality System Standard

ISO 9001 - 1994

The Design, Development, and Manufacture of Gas Water Heating Appliances done under Rinnai's Quality Management System is certified under the Quality Management System Standard ISO 9001.

Registration Number JQ0003D

Registered since: February 1994

Certified by Japan Gas Appliances Inspection Association.

Produced by Rinnai Technical Services Department

August 2004 - Issue 1.

*No portion or part of this manual may be copied without prior permission from Rinnai U.K.
Rinnai U.K. reserves the right to make modifications and change specifications without notice.*



WARNING



Failure to comply with these instructions may result in serious personal injury or damage to the appliance.

**ALL WIRING INSIDE THIS APPLIANCE MAY BE AT 230 VOLTS POTENTIAL
ALL SERVICE WORK MUST BE CARRIED OUT BY AN AUTHORISED PERSON.
DO NOT TEST FOR GAS ESCAPES WITH AN OPEN FLAME**

This manual has been published by Rinnai U.K. Technical Services. While many individuals have contributed to this publication, it will be successful only if you - the reader and customer - find it useful. We would like to extend an invitation to users of this manual to make contact with us, as your feedback and suggestions are valuable resources for us to include as improvements. Rinnai are constantly working toward supply improved appliances as well as information, and specifications may be subject to alteration at any time.

Issue N^o1

Table of Contents

Glossary of Terms and Symbols	iv
1. Introduction	1
2. Specifications	2
3. Water Flow Rates and Pressures	4
4. Dimensions	8
5. Remote Controls	9
6. Cutaway Diagram	13
7. Operational Flow Chart	14
8. Operation Principles	15
9. Main Components	16
10. Time Charts	18
11. Wiring Diagram	19
12. Dip Switch Settings	20
13. Fault Finding	21
14. Component Circuit Value Table / and checks.....	23
15. Maintenance Monitor / Error History	31
16. Gas Pressure Setting Procedure	33
17. Gas Conversion Procedure	35
18. Dismantling for Service	44
19. Exploded Diagram	50
20. Parts List	54
21. SERVICE CONTACT POINTS	58

Glossary of Terms and Symbols

dB(A)	-	sound pressure level in decibels, “A” range
DC	-	direct current
AC	-	alternating current
WFCD	-	water flow control device
FB	-	feedback information
FF	-	feedforward information
Hz	-	Hertz
IC	-	integrated circuit
kcal/h	-	kilocalorie per hour
kW	-	kilowatts
LED	-	light emitting diode
L/min	-	Litres per minute
mA	-	milliamps
mbar	-	millibars of pressure
mm	-	millimetres
bar	-	gauge pressure
OHS	-	overheat switch
PCB	-	printed circuit board
CPU	-	central processing unit
POT	-	potentiometer
rpm	-	revolutions per minute
SV	-	solenoid valve
ø	-	diameter
Δ °C	-	temperature rise above ambient
POV	-	modulating valve
TE	-	thermal efficiency
TH	-	thermistor
T _{IN}	-	temperature of incoming water
T _{OUT}	-	temperature of outgoing water

1. Introduction

The Rinnai Infinity hot water units represents the latest technology in continuous flow, temperature controlled hot water.

Features

- The Infinity 26i and HD50i NEVER RUN OUT of hot water. Whilst electricity, water and gas supplies are connected, hot water is available whenever hot water taps are open.
- Built into the main micro-processor is the facility to LIMIT THE MAXIMUM TEMPERATURE of the hot water supplied. The water temperature may be limited to various maximum temperatures. This is particularly useful when the hot water unit is installed where young children or the infirm may be using the hot water. The Infinity is delivered with a maximum preset temperature of 55° C and the HD50i at 65° C. If required, the temperature limits can be changed by a service technician. For further information, please contact Rinnai.
- The Infinity is a power flued appliance. It is COMPACT, saving both floor and wall space.
- The temperature of outgoing hot water is CONSTANTLY MONITORED by a BUILT-IN SENSOR. If the temperature of the outgoing hot water rises to more than 3° C above the selected temperature shown on the Digital Monitor (or the pre-set limit when Remote Controls are not fitted), the burner will automatically go out. The burner will ignite again once the outgoing hot water temperature falls below the temperature shown on the Digital Monitor (or the pre-set limit).
- The burner lights automatically when the hot water tap is opened, and goes out when the tap is closed. IGNITION IS ELECTRONIC, therefore there is not pilot light. When the hot water tap is off, no gas is used.
- 'Deluxe' or 'Standard' Remote Controllers are available as an optional extra. Depending on the models chosen, these offer the following additional features :
 - Bath fill function
 - Voice Prompting
 - Localised Temperature Control for up to four controllers
 - Clock
- Temperatures selected at the controllers are retained in the SYSTEM MEMORY.
- Operating NOISE LEVEL IS VERY LOW.
- ERROR MESSAGES ARE DISPLAYED on the Remote Controllers, assisting with service.

2. Specifications

Model No.	Infinity 26i and HD50i	
Type of Appliance	Temp.controlled continuous Flow Gas Hot Water Unit	
Operation	With/without remote controls, mounted in Kitchen, bathroom, etc.	
Flue System	Room Sealed - Forced Draught Flue	
Installation	Internally mounted (Indoor Only)	
Available Default Temperatures (<i>Note 1</i>): (without Remote Controllers)	40° C, 43° C, 50° C, 55° C, 60° C, 65° C, 75° C, 85° C (set by combination of Dip switches on PCB)	
Temperature Range (with Remote Controllers)	Kitchen controller	: 37 ~ 55° C
	Bathroom controller	: 37 ~ 50° C
Dimensions (mm)	Width	350
	Height	600
	Depth	224
Weight (Kg)	22	
Connections	Gas	3/4 in. BSP
	Cold Water Supply	3/4 in. BSP
	Hot Water Supply	3/4 in. BSP
Ignition System	Direct Electronic Ignition	
Max. / Min. Gas Consumption	Natural Gas	54 -- 4.4 kW
	Propane Gas	54 -- 4.4 kW
Hot Water Delivery Capacity Max.	26 to 32 L/min.	
Noise level	49 dB(A)	
Thermal Efficiency	87%	
NOXaf	55 ppm Max.	
Minimum Operating Water Flow:	2.4 L/min.	
Minimum Operating Pressure (<i>Note 2</i>):	1.8 bar	
Maximum Operating Water flow	32 L/min.	
Nominal Operating Pressure	Less than 60°C	1.4 bar
	Greater than or equal to 60°C	2.0 ~ 10.0 bar
Power Supply	Infinity Unit	AC 230 Volts (50 Hz)
	Remote Control (optional)	DC 12 Volts (Digital)
Water temperature control	Simulation feedforward and feedback	
Water flow control	Electronic Water flow sensor, flow control & heat exchanger	
	by-pass flow control.	
Safety Device	Flame Failure	Flame rod
	Boil dry	Water flow sensor
	Remaining Flame (OHS)	97° C bi-metal switch
	Over temperature	95° C lockout thermistor
	Fusible link	129° C Thermal Fuse
	Pressure relief valve	Opens 20.6 bar, closes 14.7 bar
	Combustion fan rpm check	Integrated circuit system
	Over current	Glass fuse (3 Amp).
Remote Controllers (optional)	Kitchen	MC91-1A or MC-70-2A
	Bathroom	MC91-1A or BC-70-2A
	Second Bathroom	MC91-1A or BC-70-2A
	Third Bathroom	MC91-1A
Remote Controller Cable (Optional)	Two core sheathed (double insulated) flex with min.cross-sectional area of 0.5 mm ²	
Electrical Consumption	Normal	80W
	Standby	7.5 W (with 1 Remote Control)
Manifold Electronic Control System (Optional)	MSA-2M, MSA-2S	

Note 1: The default factory setting is 55°C for the Infinity26i, and 65°C for HD50i. The unit can be ordered from Rinnai to be pre-set to any of the other temperatures listed. The unit can be pre-set to any of the temperatures listed by a suitably qualified person.

Controllers are available with default temperatures up to 75° C. When fitted with controllers, only temperatures not exceeding the default temperatures can be selected. When fitted without controllers, the unit will deliver water at the default temperature. Controllers are not available with 85° C settings.

Note 2: Unit will operate at lower pressures but the maximum rated flow of 32L/min. will not be achieved.

Sensors and Safety Devices

- Heat Exchanger Thermistor: Measures hot water temperature at heat exchanger outlet. If water temperature reaches a predetermined limit, gas supply is stopped.
- Hot Water Delivery Thermistor: Measures hot water temperature at the outlet valve (i.e. the 'mixed' temperature).
- Flame Rod: Monitors combustion characteristics inside the combustion chamber. If the flame fails, gas supply is stopped.
- Overheat Switch: Situated on the heat exchanger, gas supply is stopped when water temperature reaches 97°C for a number of seconds.
- Fusible Link: Situated on the heat exchanger, electrical power supply is stopped if the temperature exceeds 129°C.
- Water Pressure Relief Valve: Safeguards the water circuit against excessive inlet pressure. Opens at 20.6 bar, closes at 14.7 bar.
- Electrical Fuse: (3A glass fuse) prevents against over-current.
Surge Protector: prevents against over-current.
- Boil Dry Prevention: If water flow sensor detects no flow, gas supply is stopped.
- Combustion Fan Speed Sensor: In case of combustion fan defect (no rotation of fan) gas supply is stopped.
- Temperature Cutout: If the delivered hot water temperature rises above the required delivery temperature for a number of seconds, the gas supply is stopped.

Combustion Specifications

Gas Type	Injector Size (mm) Upper / Lower	Nominal TPP (mbar) * *		Gas Input (kW)	
		Low	High	Low	High
Natural	1.00	1.9	8.5	4.4	54
	1.7				
Propane	0.75	2.3	10.8	4.4	54
	1.15				

* * The TPP is measured with the cover 'off' the appliance at the regulator test point with supply pressures of 20 mbar (NG) and 37 mbar (Propane).

3. Water Flow Rates and Pressures

Water Flows

Table 1 shows unmixed and mixed water flow rates and approximate gas consumptions for various temperature rises. The unmixed flow rates are the flow rates available at the given temperature rise directly at the outlet of the water heater. The mixed water flow rates are available at the given temperature rise by mixing hot water from the outlet of the water heater with cold water from the mains supply.

Water Flows can also be calculated by the following formula:

$$M = 60 \times (Q / C \times \Delta T)$$

Where M = Water flow rate in litres/minute. If M is \leq to 26, the water is unmixed. If M is $>$ 26, the water is mixed.

Q = Heat energy output in kW = 47kW for the Infinity 26i and HD50i

C = Specific heat of water = 4.2KJ/Kg °C. C does not change for the purpose of this calculation.

ΔT = Temperature rise required (°C)

Example:

What is the flow rate available with an incoming water temperature of 10°C and a required temperature of 20°C?

$$\Delta T = 20 - 10 = 10^{\circ} \text{C}$$

$$Q = 47$$

$$C = 4.2$$

$M = 60 \times (47 / (4.2 \times 10)) = 67 \text{ l/min}$. Since 67 is greater than 26 this flow rate is mixed. This result corresponds with the value in Table 1.

Table 1: Approximate Water Flows & Gas Usage - Rinnai Infinity 26i and HD50i - Preset Table

Table 1. Approx. Water Flows & Gas Usage - Rinnai 26i and HD50i Preset Temp. Less than 60°C.


Temp Rise (° C)	5				10				15				20			
	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	
4.4-54	0.53	32	1920	1.4	13	0.53	32	1920	1.4	26	0.53	32	1920	1.4	39	
Infinity 26 i and HD 50i																
Temp Rise (° C)	25				30				35				40			
Approx. Min / Max Gas Input kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	
4.4-54	0.44	26.4	1584	1.0	54	0.37	22.2	1332	0.65	54	0.32	19.2	1152	0.5	54	
Infinity 26 i and HD 50i																
Temp Rise (° C)	45				50				55				60			
Approx. Min / Max Gas Input kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	
4.4-54	0.25	15	900	0.3	54	0.22	13.2	792	0.25	54	0.2	12	720	0.23	54	
Infinity 26 i and HD 50i																
Temp Rise (° C)	65				70				75				80			
Approx. Min / Max Gas Input kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	
4.4-54	0.17	10.2	612	0.19	54	0.16	9.6	576	0.18	54	0.15	9	540	0.17	54	
Infinity 26 i and HD 50i																

Approx. Water Flows & Gas Usage -Rinnai Infinity26i and 50i Preset Temp. Greater than or equal to 60°C


Models (Preset temps greater than or equal to 60 C)	Temp Rise (° C)		5				10				15				20							
	Approx. Min / Max Gas Input kW		L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW	L/sec	L/min	L/hr	Min Water Pressure bar	Approx Gas Cons. kW
Infinity 26 i and HD 50i	4.4-54		0.4	24	1440	2.0	10	0.4	24	1440	2.0	20	0.4	24	1440	2.0	30	0.4	24	1440	2.0	40
Models (Preset temps greater than or equal to 60 C)	Temp Rise (° C)																					
Infinity 26 i and HD 50i	4.4-54		0.4	24	1440	2.0	50	0.37	22.2	1332	1.1	54	0.32	19.2	1152	0.8	54	0.28	16.8	1008	0.6	54
Models (Preset temps greater than or equal to 60 C)	Temp Rise (° C)																					
Infinity 26 i and HD 50i	4.4-54		0.25	15	900	0.5	54	0.22	13.2	792	0.4	54	0.2	12	720	0.4	54	0.19	11.4	684	0.3	54
Models (Preset temps greater than or equal to 60 C)	Temp Rise (° C)																					
Infinity 26 i and HD 50i	4.4-54		0.17	10.2	612	0.3	54	0.16	9.6	576	0.3	54	0.15	9	540	0.27	54	0.14	8.4	504	0.25	54
Models (Preset temps greater than or equal to 60 C)	Temp Rise (° C)																					

Water Pressure

The water pressure vs flow characteristics are as follows:



4. Dimensions



5. Remote Controls


Remote Controls

Remote Controllers are an optional extra. 'Standard' and 'Deluxe' controllers can be fitted.

Standard controllers allow temperature selection only. Deluxe controllers have temperature selection, bath-fill and voice prompting functions. For detailed information regarding controller operation refer to the 'How to use your water heater' booklet supplied with the appliance. Other manufacturers' controllers are NOT compatible with this appliance.


Standard Controller (Model MC-91)

Up to 4 Standard Controllers can be fitted to the appliance. They are normally installed in the areas where the majority of hot water is used, for example, the kitchen, bathroom, ensuite and laundry.



Deluxe Kitchen Remote Control (MC-70) and (BC-70A)

Deluxe controllers have 'Kitchen' (MC-70-2A) and 'Bathroom' (BC-70-2A) versions. 'Kitchen' controls are intended for the Kitchen or other convenient area where the majority of hot water is used. Bathroom Controllers are intended to be fitted in the bathroom or ensuite and allow the user to have a bath filled to the required level and temperature automatically.



:

Up to three 'Deluxe' Controllers can be connected		
Kitchen	Bathroom	Ensuite
MC70-2A		
MC70-2A		
MC70-2A	BC70-2A	
MC70-2A	BC70-2A	BC70-2A

If a fourth Controller is required a 'Standard' Controller can be included			
Kitchen	Bathroom	Ensuite	Laundry
MC70-2A			
MC70-2A			
MC70-2A	BC70-2A		
MC70-2A	BC70-2A	BC70-2A	MC91-1A

Positioning of Controllers

Controllers must be installed in shaded and clean locations. They should be fitted out of reach of children (suggested height from floor at least 1500mm). Controllers are water resistant, however, durability is improved when positioned outside the shower recess or at least 400mm above the highest part of a sink, basin or bath.

DO NOT INSTALL THE CONTROLLERS

- NEAR A HEAT SOURCE, SUCH AS A COOK TOP, STOVE OR OVEN. HEAT, STEAM, SMOKE AND HOT OIL MAY CAUSE DAMAGE
- IN DIRECT SUNLIGHT
- OUTDOORS UNLESS AN ENCLOSURE IS PROVIDED WHICH PROTECTS THE CONTROLLER AGAINST SUNLIGHT AND DUST INGRESS.
- AGAINST A METAL WALL UNLESS THE WALL IS EARTHED IN ACCORDANCE WITH CURRENT REGULATIONS.

Remote Controller Connection

Remote controls operate at extra low voltage (12 Volts DC) which is supplied from the appliance. Controllers are supplied with 15 m of electrical cable. The cable wires for connection to the appliance are fitted with spade terminals.

Extension cables are available from Rinnai. Alternatively, a two core sheathed (double insulated) flex with minimum cross-sectional area of 0.5 mm² can be used. Maximum cable length is 50 m.

For connection refer to the “CONNECTING REMOTE CONTROL CABLES” section.

If the front cover of the appliance contains the following text install it in accordance with Diagram 1 below:

Water Heater and Controller installation configurations




Diagram 1. Max. 50° C Appliance

If the front cover of the appliance does NOT contain the above text install it in accordance with Diagram 2:




Diagram 2. Not a 50° C Appliance
Note: TLD = Temperature Limiting Device Recommended.

IMPORTANT: If the appliance is to deliver water primarily for the purposes of personal hygiene in an early childhood centre, primary or secondary school, nursing home or similar facility for young, aged, sick or disabled persons a Temperature Limiting Device (TLD), such as a Thermostatic Mixing Valve, may be required even if the appliance is set to 50°C or less. For these types of applications contact Rinnai UK.

Connecting remote control cables



Do not attempt to connect the remote control cable terminals to the appliance with the power on.
RISK OF ELECTRICAL SHOCK.

Connecting One or Two Controllers

1. Isolate the power supply
2. Remove the front cover from the Appliance (4 screws) fig. 1.
3. Thread the cable(s) through the cable access hole at the base of the appliance.
4. Connect the spade connectors to the terminals marked "Remote Control" on the printed circuit board (fig. 2). Polarity is not important. Either wire colour can be connected to either terminal.
5. Replace cover of the Appliance. Ensure that the screw with the star washer is placed at the bottom right hand corner for earthing purposes.




fig.1

Connecting Three Controllers

6. Isolate the power supply
7. Remove the front cover from the Appliance (4 screws) fig.1.
8. Thread the cables through the cable access hole at the base of the appliance.
9. Connect the 4 spade connectors to the terminals marked "Remote Control" on the printed circuit board (fig. 2). Polarity is not important. Either wire colour can be connected to either terminal.
10. Replace cover of the Appliance. Ensure that the screw with the star washer is placed at the bottom right hand corner for earthing purposes.




fig.2

Connecting Four Controllers

11. Isolate the power supply
12. Remove the front cover from the Appliance (4 screws) fig 1.
13. Cut the spade connectors from all four controller cables to be connected to the appliance (8 spade connectors should be cut off) and discard. Connect the wires from two cables and terminate into two new spade connectors as shown in (fig. 3).

Repeat for the remaining two cables. Spade connectors are available from your local electrical component retailer.

14. Thread the 4 cables through the cable access hole at the base of the appliance. Connect the 4 spade connectors to the terminals marked "Remote Control" on the printed circuit board (fig 2). Polarity is not important. Either wire colour can be connected to either terminal.
15. Replace cover of the Appliance. Ensure that the screw with the star washer is placed at the bottom right hand corner for earthing purposes.




fig. 3

MC-91A Controller Programming

Question 1: Are four Controllers connected ?

IF YES: You will need to activate the fourth controller.

STEP 1:

For the Controller in the 'KITCHEN' only, press and hold the 'Transfer' and 'On/Off' buttons simultaneously (see fig. 1) until a 'beep' is heard (approximately 5 seconds).




Fig 1.

STEP 2:

Check that the display on ALL FOUR controllers is lit and displaying a temperature when 'switched on'. If any ONE of the controller displays two dashes (see fig. 2) in the display repeat STEP 1.




Fig 2.

This completes the activation procedure. Ignore Question 2.

IF NO: (You have three controllers or fewer), go to Question 2.

Question 2: Does your kitchen controller temperature go higher than 50 deg C?

IF YES: No further action required.

IF NO: You will need to program the Kitchen controller to enable selection of temperatures higher than 50° C.

STEP 1:

For the controller in the KITCHEN only, press and hold the 'Transfer' and 'On/Off' buttons simultaneously (see fig 1.) until a 'beep' is heard (approximately 5 seconds).

STEP 2:


When the controller fitted in the KITCHEN is switched on, it should be possible to select temperatures higher than 50° C. If not, repeat Step 1.

Note:


- If the kitchen controller is replaced, repeat STEP 1 above for the replacement controller.
- If the kitchen controller is swapped with another controller (for example, the controller fitted in a bathroom), repeat STEP 1 for the controller moved from the kitchen to the bathroom. Then perform STEP 1 for the controller moved from the bathroom to the kitchen.

6. Cutaway Diagram


REU-V2632FFU-A



Infinity REU-V2632FFU / HD200I REU-V2632FFUC



8. Operation Principles



Hot Water Operation

1. Ignition

- Activate controllers (if fitted) and open the hot water tap (for full details regarding operation of controllers refer to the 'installation and user manual).
- When water flows through the unit, the water flow sensor rotates and sends an electrical 'pulse' signal to the Printed Circuit Board (PCB). This signal is proportional to the water flow rate.
- The PCB sends electrical current to the combustion fan motor causing it to turn. The fan motor sends an electrical pulse signal to the PCB. If fan rotation is OK, the main solenoid and changeover solenoid valves open as required, the spark generator activates and the spark electrode ignites the burner.

2. Water Temperature / Flow Control / Volume Control

- The PCB will automatically control operation of the internal components to achieve the programmed temperature. When a high temperature rise is required, the PCB may cause the Water Flow Servo to close partially resulting in a lower flow rate to achieve the programmed temperature. This is a necessary operational feature of the unit.
- When operating in 'Bath Fill' mode, the signal from the water flow sensor is also used by the PCB to compute the volume of water that has been passed through the unit at any instant whilst the bath is filling.

3. Shut Down

- When operating in 'Bath Fill' mode, the PCB causes the Water Flow Servo to close when the programmed Bath Fill volume has passed through the unit. Alternatively, flow is stopped when the user closes the hot water tap.
- When water flow stops, the water flow sensor stops rotating and the pulse signal to the PCB stops. The PCB then causes the main solenoid and solenoid valves to close and the burner is extinguished. The combustion fan will continue to operate for some time to purge the combustion chamber.


9. Main Components

1) Printed Circuit Board

- The Printed Circuit Board controls all operational functions including Air Supply Control, Gas Control, Water Flow Measurement, Water Flow Control, Combustion System and all sensors and safety devices.


2) Gas Flow Control

- During normal operation, the PCB keeps the main solenoid valve open whilst there is flow through the unit and the burner needs to be lit.
- Gas flow rate is controlled by the modulating valve assembly and three changeover solenoid valves to always ensure constant outlet water temperature, regardless of flow rate or incoming water temperature.
- The modulating valve is electronically controlled by the PCB using signals from the water flow sensor, water flow control device, bypass flow control device, water temperature thermistors and combustion fan speed sensor. The modulating valve directs gas to the three changeover solenoid valves.
- The three changeover solenoid valves direct gas to each of the three burner banks independently. Any one, two or all of the solenoid valves may be open during operation.
- Gas flow is modulated between 4.4 and 54 kW by a combination of the modulating valve and changeover solenoid positions.
- The maximum gas rate is predetermined and the appliance cannot be overloaded when correctly installed.



3) Water Flow Control

- Water flow is detected by a turbine coupled to a magnetic pulse generating device. The magnetic pulses are detected and counted by the PCB. The PCB calculates the exact water flow from the frequency of pulses generated by the turbine, as well as the volume of water that has passed through the unit at any instant during 'Bath Fill' operation. A minimum flow rate of 2.4 l/min is required for the burner to ignite.
- Water flow control is achieved through the use of servo driven water flow and bypass valves. Both servo motors are controlled by the PCB. The 'Water Flow Valve' restricts the flow of water into the heat exchanger assembly if the programmed temperature cannot be achieved. Also, when the Bath Fill function is activated, flow of water is stopped when the bath is full. During normal operation, cold water from the inlet valve is mixed with hot water from the heat exchanger outlet. The 'Bypass Valve' mixes the correct proportion of cold and hot water to ensure accurate hot water delivery temperature over the available range of flow rates. The water flow and bypass valves are a combined assembly on the cold



4) Air Supply Control

- Air for combustion is supplied by a centrifugal fan driven by a variable speed DC motor. The voltage to the motor is determined by the PCB based on water flow, delivered water temperature and programmed water temperature. The actual fan speed is monitored by a magnetic pulse counter. This counter emits a signal to the PCB. From the voltage supplied to the DC motor and the fan speed signal, the PCB determines whether an error condition exists with the fan.

5) Combustion System

The combustion chamber is housed within the heat exchanger assembly and comprises:

- A three chamber aluminium alloy manifold with a total of 44 integral injectors, arranged in two rows of twenty two. The middle chamber houses eight injectors, the left chamber, twelve, and the right chamber, twenty four injectors. Gas flow to each chamber is controlled by an electronic solenoid valve (refer 'Gas Flow Control' above).
- A burner assembly comprising twenty two identical modular stainless steel bunsen burners secured by an aluminised steel framework. The manifold is attached to the front of the burner module. Each bunsen burner is supplied by two injectors.
- A combustion chamber. Integrated into the combustion chamber front panel are the flame rod and two ignition electrodes.


10. Time Charts

TIME CHART


MODEL:REU-V2632FFU-A

MODEL:REU-V2632W-A

NORMAL COMBUSTION SEQUENCE




ERROR SEQUENCE (IGNITION/FLAME FAILURE)



11 FLASHING


12 FLASHING

PRE PURGE DEFECT SEQUENCE



61FLASHING





11. Wiring Diagram





12. Dip Switch Settings

WARNING: Dip Switch settings must only be changed by an authorised person.

Dip Switch Settings REU-V2632FFU & REU-V2632FFUC



REU-V2632FFU, REU-V2632FFUC Temperature Settings




* Note: ONLY models REU V2632WC & REU V2632FFUC can be converted to 85°C.

13. Fault Finding



If there is a fault with the appliance, and controllers are installed, a numerical fault code may appear on the digital display controller. If controllers are not installed, one may be fitted to find out the fault code. Fault finding without controllers (and thus fault codes) is possible but more time consuming.

To diagnose and rectify faults, the **Fault Finding Table** is used as illustrated below:



Error Code	Fault	Action	Step
3	Power Interrupt during Bathfill	Turn off all hot water taps Press On/Off on a controller twice	
10	Combustion fan overcurrent. Unit operates, then stops.	Check flue terminal for blockages Check Flue Check combustion fan.	visual W A
11	Missed or No Ignition. Unit stops without flame igniting	Check Gas Supply is correct Check Gas Valves are open Check Electrode Check Flame Rod Check Sparker Check Solenoids Check Gas Filter Check Earth Wire Check Flue Check gas pressure Check Gas Type Dip Switches for Nat. Gas or LPG.	T visual B C B D F H W manual manual
12	Flame Failure / Earth Leakage Lost Ignition	Check Gas Supply is correct Check Gas Valves are open Check Flame Rod Check Earth Wire Check Flue Check Gas Filter Check Gas Type Dip Switches for Nat. Gas or LPG. Check gas pressure Check Remote control Unhook MECS system and try the unit	T visual C H W F manual manual I
14	Thermal Fuse and/or overheat switch activated, unit operates, then stops	Check Overheat Circuit incl. Thermal Fuse (white, thermal overload wire) incl. Overheat switch (black tophat style bi-metal left of two) Check Gas Type Dip Switches for Nat. Gas or LPG. Check gas pressure Check combustion dip switch	E E E manual manual manual
16	Over temp warning. Unit operates, then stops.	Check Gas Type Dip Switches for Nat. Gas or LPG. Check gas pressure Check combustion dip switch Check water flow sensor Check water flow servo Check Heat Ex outlet temperature thermistor Check hot water outlet thermistor	manual manual manual J G K K
32	Outlet water thermistor faulty	Check hot water outlet thermistor	K
33	Heat Exchanger thermistor error	Check Heat Ex outlet temperature thermistor	K
34	Combustion air thermistor faulty	Check Combustion Air Thermistor.	K
52	Modulating Valve faulty, unit stops without flame ignition	Check modulating solenoid valve	D
61	Combustion Fan rotation error	Check combustion fan.	A
65	Water flow control servo. Water is not controlled, temp too low	Check water flow servo	G
71	Solenoid valve circuit error. Unit does not operate	Check Gas Valves are open Check Solenoids	visual D
72	Flame Rod Circuit Error. Unit does not operate	Check Flame Rod	C

-	Appliance does not operate at all. No error code on display (if there is a controller), Acts as though there is no water going through the unit and/or it is electrically dead.	Make sure that if there is a controller, it is on	visual
		Ensure there is enough water flow	S
		Check Filter	R
		Check for Air lock	M
		Check power cord is plugged in (if applicable)	visual
		Check electrical supply is turned on	visual
		Check Non Return Valves and Mixers in System	L
		Check Gas Valves are open	visual
		Check for short circuits	visual
		Check Remote control	I
		Check Power supply voltage	N
		Check electrical fuses	O
		Check Surge protection	P
		Check Earth Wire	H
		Check water flow sensor	J
		Check transformer	Q
		Check Sparker	B
-	No combustion despite remote control indicating that combustion is occurring - if remote controllers are installed	Check water flow sensor	J
		Check Flame Rod	C
		Check Heat Ex outlet temperature thermistor	K
		Check hot water outlet thermistor	K
		Check combustion fan.	A
		Check Sparker	B
		Check Gas Valves are open	visual
-	Combustion stops during operation.	Check Overheat Circuit	E
		Reset unit if there was a power cut	
		Check Remote control	I
		Make sure that if there is a controller, it is on	visual
		Check Gas Supply is okay	T
		Unhook MECS system and try the unit	
		Check Flame Rod	C
		Check Flue	W
		Check Earth Wire	H
-	Cannot adjust the hot water temperature via the controllers - only if controllers are installed.	Check Power supply voltage	N
		Check hot water outlet thermistor	K
		Check Heat Ex outlet temperature thermistor	K
		Check Gas Valves are open	visual
		Check water flow servo	G
		Check Non Return Valves and Mixers in System	L
		check bypass servo	G
-	Anti - Frost Heater does not operate.	Check Solenoids	D
		Check anti frost heater components	U
-	Upon commissioning the gas pressure will not achieve correct high pressure	Check frost sensing switch	V
		Check Gas Supply is correct	T
		Check Gas Filter	F
		Check flue terminal for blockages	visual
		Check Flue	W.

Fault Finding Steps.

A. Combustion Fan Circuit.

The voltages should be checked while the unit is On, and water is flowing. The meter leads can be inserted into the connection plug. To test the resistances electrically isolate the water heater, unplug the connector at fan motor, and measure the resistances through the motor.

Black – Red	6 – 45 Vdc	do not check Resistance
White – Black	6 – 45 Vdc	9.2 – 9.4 kOhms
Yellow – Black	11 – 13 Vdc	3.5 – 3.9 kOhms

If Black – Red voltage is incorrect (while the fan should be running) replace the pcb.

If Yellow – Black voltage is incorrect replace the pcb

If Yellow – Black resistance is incorrect replace the fan motor

If White – Black voltage or resistance is incorrect replace the fan motor.#

B. Ignition System.

The best check for the ignition electrode and sparker is to listen to the unit for the ticking sound as it sparks. If it is ticking the sparker sub pcb is working. Remove the electrode and visually inspect for damage.

Check the thick black HT lead from the sparker box to the electrode. Be sure that connections on both ends are tight and the lead has not been damaged. Measure the resistance through the wire if it looks as though it may be damaged. The resistance should be very low.

Sparker box / sub pcb

Test to make sure that the sparker is getting a signal from the pcb. The two grey leads from the sparker to the pcb are broken by a connector plug. At this plug measure the voltage. Put the meter leads into the plug, power the heater, then turn on the water. It will only give a quick voltage reading.

Grey – Grey 90 – 110 Vac.

If this is not correct replace the pcb (it is acceptable to be a bit higher.)

If it is correct unplug the connector and measure the resistance through the sparker.

Grey – Grey over 1 M Ohm (1000 k Ohms)

If this is not correct replace the sparker box / sub pcb.

If this is correct, but the electrode is not sparking then visually inspect the electrode, clean it, set the gap, or replace it.

C. Flame Rod.

If the flame rod circuit is faulty the error code will be either 11 or 72.

If 72 is the error disconnect flame rod and cycle unit. If it is 72 again then refer to section on hot water temperature thermistor. If 72 is not displayed, check for electrical current leaks, and continue with this section.

First check to make sure all connections are tight. If not, tighten them and adjust the flame rod.

With the unit running measure the voltage (AC) from the flame rod connection spade (that the yellow wire with the grey covered spade connector fits on) to earth. Do this with the unit on and burning. This will cause the unit to lockout so the reading will only be brief. Check the resistance as well, this should be done with the unit off and the yellow flame rod spade connector unplugged. Measure the resistance through the flame rod, not the pcb.

FR – E 5 – 150 Vac over 1 M Ohm

If the voltage is correct, replace PCB

If the voltage is incorrect, replace flame rod.

If the resistance is correct, replace the pcb

If the resistance is incorrect, replace the flame rod.

Another check is the current from the flame rod to the pcb. This is measured by placing the meter in line between the flame rod and the pcb. Unplug the connector at the flame rod and put one meter lead on the spade, and one in the spade connector.

Current should be over 1 micro (μ)Amp

If current is more than this the pcb is faulty.

If current is less than this the flame rod is faulty or needs cleaning.

D. Solenoid Valves.

There are 4 solenoid valves and one modulating valve. Three of the solenoids are burner sectional solenoids, and the fourth is the main, safety solenoid.

All solenoids should be tested for voltage and resistance. The resistance is measured with the unit electrically isolated and the connector unplugged. The resistance is measured by putting the meter leads on the connections and measuring through the solenoid. The voltage is tested while the unit is running and the connections are made. While the unit is lit put the leads into the plug and measure the voltage (AC.) Remember that the sectional solenoid valves may not be open if the unit is not on full flame.

Main SV	Pink – Black	80 – 100 Vdc	1.7 – 2.1 k Ohms
SV1	Black – Yellow	80 – 100 Vdc	1.7 – 2.1 k Ohms
SV2	Black – Blue	80 – 100 Vdc	1.7 – 2.1 k Ohms
SV3	Black – Brown	80 – 100 Vdc	1.7 – 2.1 k Ohms
Modu SV	Pink – Pink	2 – 15 Vdc	67 – 81 Ohms

If the voltage is incorrect replace the pcb.

If the resistance is incorrect replace the solenoid valve.

If the resistances are correct and there is no voltage to the solenoids proceed to Thermal Fuse Circuit (E.)

If the resistances and voltages are correct continue.

Check the secondary gas pressure change when the set temperature is changed from 37 to 55°C.

The secondary pressure should change. If it does, go to the water flow servo circuit (G.) If the pressure does not change replace the modulating valve.

E. Thermal Fuse (Overheat) Circuit.

First locate the Overheat circuit. It is made up of red wires making a loop through the unit, including a number of thermal fuses, and overheat bi-metal switches. Along the right-hand side of the unit the red wires can be seen running up the side of the unit above the pcb to the first overheat sensor. There are two connection plugs on these wires.

With the unit electrically isolated unplug the lower of these connections (if you unplug the higher one you will not be testing the entire circuit.) Put your leads in the plug and measure the resistance through the overheat circuit (not the pcb)

Resistance should be less than 1 Ohm.

If the resistance is greater than 1 Ohm test each individual sensor to find which one is faulty and replace it AFTER checking the heater for damage. Check that the gas type and combustion dip switch settings are correct. Confirm gas pressure when the unit is operating again.

F. Gas Filter.

There is an inline gas filter in the inlet pipe work. If the gas pressure will not achieve the correct level, and the inlet pressure is correct (20mbar) then drop the gas connection out to see whether there is a blockage in the filter.

G. Water Flow Servo Circuit and Bypass Servo Circuit.

The simplest checks for the water flow servo and the bypass servo are visual and audio. When the unit is isolated, and then powered back up you should hear the bypass and the flow servo close completely, and then open completely to its standby position. If this is done with the tap open the water flow will be stopped and then will restart. If this does not happen or if it does not sound right one of these servo motors is probably faulty.

To determine which one isolate the water connections, then remove the clips holding in the internal pipes making up the bypass and heat exchanger flows. These are facing out just above the cold water connections. When you have removed the clips these pipes can be pulled out and separated so that the servo can be viewed inside the pipe connection. The front one that can be seen is the bypass. Turn the power off, then back on to watch it shut then open. If it is operating correctly, remove the bypass servo (two screws into the water flow manifold behind it) and do the same thing as before to watch the water flow servo shut then open.

If one of the servos is not operating correctly it is probably the servo motor, but could potentially be the pcb. Continue on.

Water Flow Servo Circuit.

From the water flow servo circuit there are 6 wires. Follow them towards the pcb until you find the connector plug. This is where you will do the tests.

First electrically isolated the unit, disconnect the 6 wire plug and measure the resistance between red and blue across the motor (not the pcb)

Resistance should be 10 – 30 Ohms.

If the resistance is incorrect replace the water flow servo and water flow sensor.

If the resistance is correct then power the unit (still with the connector unplugged) and measure the voltage from the pcb by putting the meter leads into the other plug.

Orange – Grey 11 – 13 Vdc

If this is faulty replace the pcb.

If this is correct connect the 6 wire plug, and make sure the heater has power, but there is no water flowing (standby mode with the water flow servo fully open, if you are unsure, confirm this with the deluxe controller)

Brown – Grey 4 – 6 Vdc

Yellow – Grey less than 1.0 Vdc

If either of these values are incorrect replace the water flow servo and water flow sensor.

Bypass Servo Circuit.

From the bypass servo circuit there are 5 wires. Follow them towards the pcb until you find the connector plug. This is where you will do the tests.

First electrically isolated the unit, disconnect the 5 wire plug and measure the resistance between the following across the bypass servo motor (not the pcb)

Brown – White 15 – 35 Ohms

Orange – White 15 – 35 Ohms

Yellow – White 15 – 35 Ohms

Red – White 15 – 35 Ohms

If any of these are incorrect replace the pcb.

If these are correct connect the 5 wire plug and measure the voltage while the unit is operating.

Brown – White 2 – 6 Vdc

Orange – White 2 – 6 Vdc

Yellow – White 2 – 6 Vdc

Red – White 2 – 6 Vdc

If these values are incorrect replace the bypass servo.

H. Earth Lead.

Check to make sure that all earth leads are connected and there are no breaks or short circuits. Checks should be made at the earth lead, pcb, power cord, and surge protector. If there is a loose connection the Ignition electrode and flame rod will not work because they need to flash to earth. Tighten any loose connections.

I. Remote control.

Check the voltage between the terminal connection points on the pcb. Do this with the unit in standby mode (power on, water off)

normal voltage: 11 – 13 Vdc.

If this is correct check the remote wire for damage or shorts. If this is alright disconnect the remote and turn on the water. If the unit operates correctly replace the remote control.

If the voltage is incorrect check the water flow servo (G) before replacing the pcb. If the water flow servo circuit is working correctly replace the pcb.

J. Water Flow Sensor.

The water flow sensor is located inside the water heater immediately as the cold water enters the unit. From that there are 3 wires (red, yellow, black) running to the pcb, there is a connector plug in between the sensor and the pcb for testing. Measure the voltage with the water heater powered up and water running through the unit. If there is a remote attached make sure it was turned on before the water began running through the unit.

Black – Red	11 – 13 Vdc
Yellow – Black	4 – 7 Vdc

If Black – Red is incorrect replace pcb

If Yellow – Black is incorrect replace water flow sensor. Before you replace the water flow sensor be sure you have checked the filter (R) and for air locks (M).

K. Thermistors.

Check all thermistors by unplugging thermistor lead and inserting meter ends into both sides of thermistor plug and measuring resistance on the 20 k Ohms scale. Apply heat to the thermistor bulb and watch the resistance decrease. Apply ice to the thermistor bulb and ensure the resistance increases.

Thermistor values should read about:

15°C : 11.4 – 14 k Ohm

30°C : 6.4 – 7.8 k Ohm

45°C : 3.6 – 4.5 k Ohm

60°C : 2.2 – 2.7 k Ohm

If there is a break in the circuit the resistance reading will be over 1 M Ohm.

If there is a short circuit in the wire the reading will be less than 1 Ohm

If either of these occur the thermistor should be replaced.

Heat Exchanger Thermistor

This thermistor is located on the right hand side of the unit, at the top where the water leaves the heat exchanger.

Hot Water Outgoing Thermistor

This thermistor is located at the bottom left of the water heater where the water exits the water heater.

Combustion Air Thermistor

This thermistor is located in the combustion air fan. To find it the first time you may need to remove the combustion air fan. Do not pull the fan out too quickly or you will ruin the thermistor.

L. Check Non Return Valves and Mixers in System

Non Return valves and mixing valves occasionally have a tendency to pass cold water, especially if there is a mismatch of pressures. The easiest way to check for this is to isolate the valves on the water heater and turn on all the hot taps, one at a time. If there is a flow of water (besides the initial flow which is in the pipework) then there is a mixer valve or non return valve in the system passing.

There is another way to check non mixers and non return valves, especially in situations where the temperature varies or is only warm. Isolate the hot water outlet somewhere between the water heater and the first draw off. If there is a circulating loop (secondary return) isolate this as well. Now if you open the pressure relief valve of the water heater or a drain off point somewhere between the hot water outlet and the valve that has been isolated the only water that will travel through the water heater will be mains water at fairly constant temperature. Measure the outlet temperature at this drain off point. If the temperature is constant, and correct for the setpoint, then the water heater is working as it should and you need to find the mixing valve or non return valve that is faulty.

M. Air Locks in the Heat Exchanger.

Upon commissioning, if the water heater is the highest point of the system the heat exchanger may experience an air lock.

To clear it, isolate the hot water outlet and open the pressure relief. The incoming mains should push the air lock out and the unit will fire.

N. Check Power Supply to the unit.

To make sure there is power to the unit make sure all the electrical isolators are On and the fuses are okay. With your meter check for 240Vac on the bottom connection plug of the surge protection. Do this with the connector plugged in, and the unit in standby mode (power on, water off.) Stick the meter leads in the blue and brown plug.

If there is no power at this point you must find where the connection has been lost.

O. 3 Amp Fuses

The unit has two inline 3 Amp fuses. Remove the fuse and check for continuity through. If there is continuity the fuse is good, if not replace it.

P. Surge Protection sub pcb

The surge protection sub pcb is located in a small white box on the front of the main pcb. It is below the dip switches. If you follow the main power cable into the unit it will lead you to the surge protection sub pcb

After checking to be sure there is power incoming (240 Vac on the bottom connection between blue and brown) check the top connector of the surge protector. Put your meter leads into the plug (while it is connected) with the two white wires. You should get 207 – 274 Vac. If not and you have incoming mains to the bottom of the surge protector, replace the surge protector.

Q. Transformer.

There is one transformer on the 26i located in the back behind the pcb. To access it remove the top and bottom screw holding in the pcb and pull the pcb out. Let it hang from its wires, but be careful not to damage it or pull on it.

Test the transformer in standby mode (unit on, water off.)

First check the voltage from the surge protection sub pcb. This is detailed in section P. The blue and brown wires from the surge protector go directly to the transformer, so if there is power from the surge protector there is power to the transformer (check for loose connections.) From the transformer come two wires, black and white. These run back to the pcb. As the pcb is already out, you can check the voltage from the transformer at the pcb. With your meter check Voltage AC by putting your leads in to the connector (while connected) of the black wire and the white wire (with a grey wire as well.)

The voltage from Black – White should be about 100Vac.

For this unit the 100Vac to low voltage dc is done on the pcb. If you need to verify there is low voltage dc follow the procedure for the water flow sensor (J) and check for 12 Vdc signal between black and red.

R. Filter.

Below the water heater, on the cold water connection is a brown plug. Isolate the water supply and remove this brown plug. It holds a small micron basket strainer. The strainer becomes clogged easily, especially after installation. When it is clogged sometimes water will travel through the unit without triggering the flow sensor. Make sure you check any external Y-strainers as well

S. Water flow.

To operate there must be at least 2.4 l/min flowing through a Rinnai water heater. If there is multiple heaters, installed without PAM valves or a MECS system then there must be 2.4 l/min per heater. A modern wash hand basin could be as low as 3 or 4 l/min, so if there is no means of staging the heaters they may not operate. Isolate all the units except one to find out.

This problem could also crop up with a pumped secondary. Make sure the combination of the pump capacity, and the staging of the units is compatible.

The flow rate from your tap can be determined with a Weir cup, or a deluxe controller. The deluxe controller manual explains the diagnostics function. If you are not getting enough flow at an outlet, and you used to, check the filter (R.)

T. Gas Supply.

If the unit suddenly goes off you will need to check the gas supply. This is easy when operating on natural gas, and is done by checking the inlet pressure. Other things to check are the meter size, compared to other appliances total offtakes. If the unit has just been installed there may be air in the line, be sure it is fully purged.

If the unit is on LPG make sure that you visually examine the tank or bottles to be sure they are not freezing up. If they are then there is not enough gas. Check the regulators to be sure they will pass enough gas for the system.

For both LPG and natural gas you will need to confirm that the gas pipe size is correct. You may need to check the gas filter (F.)

U. Check anti frost heater components

The unit has five frost protection heaters mounted on the water pipes to protect them from freezing. The heaters are white ceramic resistive heaters, and come on around 5°C. The voltage through the heaters, when active, is 240Vac. The heaters are located as follows. There is a valve heater in the mains incoming (where the flow sensor is) and another valve heater in the outgoing hot water valve (next to the hot water thermistor.) There are two square pipe heaters, on the left side of the water heater, one on the mixed water pipe (heat exchanger + bypass), and one on the bypass. The fifth one is located on the front of the unit, at the top on the heat exchanger outlet.

Each heater element can be tested by measuring the resistance through them one at a time.

The valve heater resistance should be 50 – 56 k Ohms

The square heaters and the other valve heater should be 444 – 510 k Ohms

The entire anti frost heater system is done as a kit, so the easiest check is to see if they heat up when the sensor is closed. If not, replace the system. There will be 240 Vac through the heaters if the system is working so take care.

V. Frost Sensing Switch

The frost sensing switch is located a short distance upstream (to the right) of the long, cylindrical frost heater. It is a black, top hat style bi-metal switch. It is a normally open contact so to prove it is working it must be cooled to about 5°C. At this temperature the resistance in the switch can be tested, it should be less than 1 Ohm.

W. Check Flue

If there are combustion problems they could be due to the flue. Is the flue too long? The maximum flue run is 15m, less 2m per bend, to a maximum of 4 bends. Regardless of the length of flue the maximum height off the water heater to the terminal is 9m. If there is a condensate trap installed, be sure it is the right way up (with the male section at the bottom.)

14. Component Circuit Value Table

Table Reference	Component	Measurement Point		Normal Value	A Note
		CN	Wire Colour		
	Surge Protection	F ₅	B-Br	AC207~264V	
B	Water Flow Control Device	B ₂	R-B	DC11~13V	Operate Electricity
			Gy-Or	DC11~13V	Control Electricity
			Gy-Y	Below DC1V (Limiter On)	Full Open Position
				DC4~6V (Limiter Off)	
			Gy-Br	Below DC1V (Limiter On)	Full Close Position
				DC4~6V (Limiter Off)	
	By-Pass Flow Control Device	G ₁	Br-W Or-W	DC2~6V	Operate Condition
			Y-W R-W GND	15~35Ω	
	Remote Control	D ₁	Bk-Bk	DC11~13V	
D	Water Flow Sensor	B ₄	R-Bk	DC11~13V	
			Y-Bk GND	DC4~7V (Pulse 17~460Hz)	
E	Combustion Fan	A ₁	R-Bk	DC6~45V	
			Y-Bk	DC11~13V	
			W-Bk GND	DC5~10V (33~400Hz)	
	Flame Rod	C ₁	Y-BODY EARTH	AC5~150V	After Ignition
			Y-FLAME ROD	Over DC1μA	Flame Condition
C	Modulating Valve	C ₂	P-P	DC2~15V 67~81Ω	
A	Outgoing Thermistor	B ₅	W-W	15° C ∙ 11.4 ~ 14.0kΩ	
	Heat Exchanger Outgoing Thermistor	B ₆		30° C ∙ 6.4 ~ 7.8kΩ	
	Air Thermistor	B ₁	W-W	45° C ∙ 3.6 ~ 4.5kΩ 60° C ∙ 2.2 ~ 2.7kΩ 100° C ∙ 0.6 ~ 0.8kΩ	
	Thermal Fuse	B ₃	R-R	Below 1Ω	
		C ₃			
	Igniter	F ₆	Gy-Gy	AC90~110V	
C	Main Solenoid Valve	E ₁	P-Bk	DC80~100V 1.7~2.1kΩ	
	Solenoid Valve 1	E ₂	Y-Bk	DC80~100V 1.7~2.1kΩ	
	Solenoid Valve 2	E ₃	B-Bk	DC80~100V 1.7~2.1kΩ	
	Solenoid Valve 3	E ₄	Br-Bk	DC80~100V 1.7~2.0kΩ	
	Transformer	F ₅	B-Br	16~18Ω	
		F ₇	W-Bk	AC90~110V	
F	Valve Heater	F ₃		50~56kΩ	
	Valve Heater and Square Heater	F ₂	Y-Y	444~510kΩ	
		F ₃	Y-Y		


15. Maintenance Monitor / Error History

This feature is available where the appliances are connected with a deluxe controller (MC70 or BC70). This will enable service personnel to locate the maintenance history and faulty components, with the appliance in operation.

NB. When the maintenance information, error history is shown, use only one controller. If two or more remote controls are used at the same time, it may not operate correctly.

To display Maintenance Information

16. With the controller in the "OFF" position press the Water Temperature "DOWN" (Cooler) button while holding the "ON/OFF" button to activate the maintenance monitor. Press the "ON/OFF" button a second time to set the controller in the "ON" mode. This feature can now be used with the appliance in operation.



17. The maintenance number will be shown in the Water Temperature display.

18. Data will be shown in the Clock display.

19. To select the required maintenance number, press the Water Temperature "UP" and "DOWN" buttons.

Note: Infinity 26i and HD50i use Maintenance Numbers 1-12.

Display Monitor Contents			
No.	Contents	Units	Data Range
01	Water flow sensor recognition flow (Example 123 = 12.3L/min).	0.1L/min	0~400
02	Hot water Outlet thermistor temperature (Example 20 = 20° C)	° C	0~999
03	Hot water combustion time (Example 6 = 600 hours)	100 hours	000~999
04	Hot water operation frequency (Example 6 = 600 Operations)	100	0~999
05	Hot water fan frequency	Hz pulses/sec	0~999 *Note 1

*Note 1 Fan Frequency rpm Conversion

$$(\text{rpm}) = (\text{Hz}) \times 15$$

06	Remote control connection	none	0 or 1 *Note 2
----	---------------------------	------	----------------

*Note 2 Remote Control Connections

Bathroom Remote		Kitchen remote	
Additional remote			
“0”	1	1”	

Controls connected	Display
No	“0”
Yes	“1”

07	Water flow servo present recognising positioning	None	0~2 *Note 3
----	--	------	-------------

***Note 3 Water Flow Servo Positioning**

Servo Position	Open	Centre	Closed
Display	"1"	"0"	"2"

08	Inlet water temperature (PCB recognition value) (Example 25 = 25 ° C)	° C	0~999
09	Hot water fan current flow value (Example 6 x 10 = 60 mA)	10 mA	0~999
10	Bath fill amount (this counts the litres during bath fill operation).	Litres	0~999
11	Heat exchanger exit thermistor temperature Example 55 = 55 ° C)	° C	0~999
12	Bypass servo present recognition positioning (Example 0 = Closed 160 = Half open 320 = Open)	Degrees	0~320

To return to normal operation

- Press the ON/OFF button again while holding down the Water Temperature "DOWN" (Cooler) button.



Error History

To Display Error Memory (History)

(This feature will show the last 10 faults in sequence)

1. Turn off at the ON/OFF button. (This can be done during operation)
2. Press the ON/OFF button while holding the Water Temperature "UP" (Hotter) button.

- The Sequence will be shown in the Water Temperature display.
- Error Code will be shown in the Clock display. (See service Manual for error codes).
- Where there are less than a total of 9 errors, "FFF" or " - - " will be displayed in the Clock display.



To return to normal operation.



- Press the ON/OFF button again while holding the Water Temperature "UP" (Hotter) button.
- This feature will automatically shut down after 3 minutes.

16. Gas Pressure Setting Procedure



The regulator on the Infinity is electronically controlled and factory pre-set. Under normal circumstances it **does not** require adjustment during installation. Perform this procedure only if the unit is not operating correctly and **all** other possible causes for incorrect operation have been eliminated.

- 1) Turn 'OFF' the gas supply
- 2) Turn 'OFF' 230V power supply.
- 3) Remove the front cover from the appliance.
- 4) Check gas type switches (fig. 1) are in the correct position (bottom set or SW2 of switches).



- 5) Attach pressure gauge to burner test point. (fig. above right)
- 6) Turn 'ON' the gas supply.
- 7) Turn 'ON' 230V power supply.
- 8) If remote controllers are fitted, turn the unit 'ON' at the kitchen controller, select a delivery temperature of 55°C and open a hot water tap fully. (CAUTION: Ensure building occupants do not have access to hot water outlets during this procedure.
- 9) Set the Infinity to 'Forced Low' combustion by setting No. 7 dipswitch of the top (SW1) set of dip switches to 'ON'. (fig.3)
- 10) Check the burner test point pressure.





Fig. 3

- 11) Adjust the regulator screw on the modulating valve as required to the pressure below. (fig 4)

Pressure Setting low	
N.G.	1.9 mbar
Propane	2.3 mbar




Fig. 4

- 12) Set the Infinity to 'Forced High' combustion by setting both No. 7 and No. 8 dipswitches of the top (SW1) set to 'ON'. (fig 5) Ensure maximum water flow.
- 13) Check the burner test point pressure.
- 14) Adjust the high pressure Potentiometer (POT) on the Printed Circuit Board (PCB). As required to the pressure shown.




Fig. 5

Pressure Setting high	
N.G.	8.5 mbar
Propane	10.8 mbar

- 15) **IMPORTANT:** Set dip switches No's 7 and 8 on the top (SW1) set of switches to 'OFF' to return the appliance to 'Normal' combustion.
- 16) Close hot water tap.
- 17) Turn 'OFF' the gas supply and 230V power supply.
- 18) Remove pressure gauge, and replace sealing screw.
- 19) Turn 'ON' the gas supply and 230V power supply.
- 20) Operate unit and check for gas leaks at test point.
- 21) Replace the front cover of the appliance.



Warning

DURING PRESSURE TESTING OF THE INSTALLATION ENSURE GAS VALVE SITUATED BEFORE UNIT IS SHUT OFF.
FAILURE TO DO SO MAY RESULT IN SERIOUS DAMAGE TO THE APPLIANCE AND POSSIBLE INJURY.


17. Gas Conversion Procedure



Gas Conversion Method


Tools required: Screw Driver and Digital Manometer

- ① Turn OFF main gas valve
- ② Disconnect 230V power supply
- ③ Remove Front Cover
- ④ Remove Remote Control



Replacement of Manifold


- ① Remove Flame Rod Connection terminal
- ② Pull off high tension lead



- ③ Remove Manifold assembly


[Screws (9)
 Manifold - Gas Control (3)
 Manifold - Burner (6)]

Clean combustion deposits on the burner if necessary




- ④ Replace Manifold fit Gasket to Gas Control.

For NG: U245-200-D 101-560-000
 For Propane: U245-200-A 101-559-000




⑤ Change Gas Type Switch on PCB



LPG	NG
<div> <div>OFF</div> <div> <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 </div> </div>	<div> <div>→ ON</div> <div> <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 </div> </div>

Pressure Setting



- ① Remove pressure test point sealing screw from gas control
- ② Connect digital manometer with test point



- ③ Turn ON 230V power supply
- ④ Turn ON remote controller switch
- ⑤ Turn ON main gas valve fully

- ⑥ Change Dipswitch No. 7 for low combustion
- ⑦ Turn ON outgoing water tap
- ⑧ Set pressure low with solenoid valve adjustment


	Low Capacity mbar
N.G.	1.9
Propane	2.3



⑨ Change Dipswitch No. 7 & 8 to ON for high combustion.

⑩ Set high capacity pressure with adjustment volume on PCB

	High Capacity mbar
N.G.	8.5
Propane	10.8



⑪ Return Dipswitch No. 7 & 8 to OFF position

⑫ Turn OFF outgoing water tap


⑬ Disconnect 230V power supply

⑭ Fit pressure test point sealing screw

⑮ Check leakage from gas control, manifold connection and pressure point sealing screw

⑯ Refit front cover

⑰ Turn ON 230V power supply



Anti Frost Heater Installation

Fitting method

1. Turn off and disconnect the 230V power supply.
2. Turn off the water supply and relieve the water pressure in the water heater.
3. Remove front cover.
4. Fit the Frost sensing switch (92092170). This is the black sensor with the built in brackets and clips vertically on the water tube at the top right hand side of the heat exchanger next to the thermistor. (See note ①, Diagram 1).
5. Fit the long white round Anti-frost heater (92093293*) with two hook brackets (92076123) to the lower tube on the front of the heat exchanger. (See note ②, Diagram 1)
6. Using the clip brackets (92093301) fit the two square Anti-frost heaters (92093293*), one heater is to be fitted under the hot water outlet tube while the other is to be fitted one along the side of the cold inlet tube. These are located on the left hand side of the heat exchanger and can be easily accessed without removing any components. (See note ③, Diagram 2)
7. On the hot water outlet connection block located in the lower left hand side, carefully loosen the screw retaining the stainless steel bracket. Without disturbing the water seal twist the bracket anti-clockwise to clear the hole in the block, insert heating element (92093293*), refit bracket and tighten the retaining screw. (See note ④, Diagram 3)
8. On the cold water inlet servo valve located in the lower center of the unit, remove the retaining screw insert the Valve heating element (92092261) refit the retaining screw. (See note ⑤, Diagram 3)
9. Ensure all polarized plugs are connected and support wiring loom in existing anchor ties.
10. Connect the Anti-frost wiring loom (92093293*) to the polarized plug on the main 240V loom located directly after the fuse holders.
11. Turn on water supply and ensure there are no water leaks on the hot water outlet joint.
12. Refit the front cover.
13. Restore the power supply.

Part	RA Part Number	Drawing Number	Qty.
Frost sensing switch	92092170	U242-511	1
Anti-frost loom/heaters*	92093293	U245-775	1
Valve heater	92092261	U245-776	1
Heater mounting bracket	92093301	CF29-742X01	2
Heater mounting bracket	92076123	AU100-721X03	2

*Note: Anti-frost wiring loom is supplied with four factory fitted heating elements.




Diagram 1. (Front elevation)




Diagram 2. (Side elevation left)




Diagram 3. (Front elevation "Lower")

18. Dismantling for Service



230 Volt potential exposure. Isolate the appliance and reconfirm with a neon screwdriver or multimeter.

<i>Item</i>	<i>Page</i>
1. "Removal of the Front Panel"	42
2. "Removal of the PCB Unit"	42
3. "Removal of the Water Flow Sensor, Servo and Bypass Servo"	42
4. "Removal of the Bypass Servo"	42
5. "Removal of Transformer"	43
6. "Removal of Sparker"	43
7. "Removal of the manifold and burner unit"	43/44
8. "Removal of the Gas Control"	44/45
9. "Removal of Flame rod and spark plug"	45
10. "Removal of outgoing water thermistor"	45
11. "Removal of heat exchanger thermistor"	45
12. "Removal of air intake thermistor"	45
13. "Removal of Bypass Servo"	46
14. "Removal of Anti Frost Switch"	46
15. "Removal of Anti Frost heater"	47
16. "Removal of the Fan Motor"	47
17. "Removal of Heat Exchanger"	48
18. "Removal of Thermal Fuse"	49

Unless otherwise stated, re-assembly is the reverse of dismantling.

IMPORTANT

For some areas of dismantling you may need to isolate any or all of the following:

- * Isolate gas supply.
- * Disconnect electrical supply from wall socket.
- * Isolate water supply.
- * Drain all water from appliance.

1) Removal of the **Front Panel**

- a. Remove four (4) screws.



2) Removal of the **PCB Unit**

- a. Remove the front panel. (Refer Item 1.)
- b. Remove two (2) PCB unit fixing screws and pull out forward.



3) Removal of the **Water Flow Sensor, Servo and Bypass Servo**

- a. Remove the front panel. (Refer Item 1.)
- b. Remove two (2) screws and locking plates located on the water supply pipe and bypass pipe. Pull bypass pipe and water supply pipe forward to clear servo valves. Ensure O-rings are not lost or damaged.




4) Removal of the **Bypass Servo**

- c. Remove two (2) screws from the water flow servo body, and pull the bypass servo out forwards. Ensure O-rings are not lost or damaged.




5) Removal of **Transformer**

- Remove PCB (Refer to 2)
- Remove 100 V harness and 2-pin connection




c. Removal Transformer




6) Removal of **Sparker**

- Remove sparker
- Remove 3 pin connector
- Remove high tension cord




7) Removal of the **manifold and burner unit**


- Remove high tension cord and flame rod.
- Remove 2 pin connection of the solenoid valve
- Remove manifold.




Manifold Assembly



- a. Remove combustion chamber front panel.
- b. Remove burner unit.




- c. Pull off burner unit




8) Removal of the Gas Control


- a. Remove manifold (refer to 5)
- b. Remove back tube
- c. Remove gas connection.



- d. Pull off connectors for gas control modulation valve and solenoid valve.




Gas Control




9) Removal of Flame rod and spark plug

- Remove flame rod terminal and tighten span cord.
- Remove flame rod and spark plug.




- Remove of High Tension lead



10) Removal of outgoing water thermistor

- Remove thermistor fixing screw.
- Remove 2 pin connection outgoing water thermistor




Heat Exchanger Thermistor




11) Removal of heat exchanger thermistor


- Remove thermistor holder
- Remove 2 pin connector



12) Removal of air intake thermistor


- Remove fan motor
- Remove 2 pin connector of inlet thermistor
- Remove inlet thermistor (care with O-ring)
- Thermistor






13) Removal of Bypass Servo

- a. Remove fan motor (Refer to 14)
- b. Remove 3 pin connector
- c. Remove 2 pin connector
- d. Remove 6 pin connector and 5 pin connector
- e. Remove bracket for water connection tube.




f. Removal of inlet water connection




- g. Remove bypass servo and water flow servo
- h. Remove fitting screws of bypass servo

i. Flow sensor and water flow servo



14) Removal of Anti Frost Switch

- a. Remove 2 pin connection for anti frost switch
- b. Remove Anti Frost switch





c. Anti Frost switch




15) Removal of Anti Frost heater

- Remove 2 pin connection of Anti Frost heater
- Remove bracket of hot water connection.
- Remove Anti Frost heater.




16) Removal of the Fan Motor



- Remove 4 pin connector
- Remove 2 pin connector of solenoid valve.



- Remove joint bracket
- Remove connection joint from the fan motor
- Remove fan motor screw




- Remove fan motor




17) Removal of Heat Exchanger


- Remove PCB
- Remove fan motor
- Remove 2 pin connector of thermal fuse
- Remove flame rod terminal of high tension cord
- Remove anti frost heater switch
- Remove 2 pin connector
- Remove 3 pin connector
- Remove back pressure tube
- Remove air intake.




- Remove fixing screw




- Remove fixing screws of the heat exchanger unit




- Remove heat exchanger screws




- Remove Bypass tube



- Pull out heat exchanger screws



- Remove manifold and burner unit.
- Remove thermal fuse, over heat switch, sparker, hex thermister and back pressure joint.




18) Removal of Thermal Fuse


- a. Remove heat exchanger.
- b. Remove Thermal Fuse

After removal of thermal fuse fitting procedure is as follows:


Heat Exchanger Front




Heat Exchanger Rear




Heat Exchanger Left





Heat Exchanger Right




19. Exploded Diagram









20. Parts List

No	Part Name	RJ Drawing No	RUK Part No.	26i	HD50i
001	BODY Assy, Main - Wh	U245-100-3X04		1	
001	BODY Assy, Main - Sil	U245-100-3X04			1
002	BRACKET - Mtg.	U242-111-2X02		1	
002	BRACKET - Mtg.	U242-111-7X02			1
004	PANEL, Conn. Reinf.	U245-120X03		1	1
005	SHIELD, Heat Ins.	U245-107			
006	PANEL, Fr - Wh	U245-110-3-A	92092055	1	
006	PANEL, Fr - Sil	U245-110-5-B	92092493		1
007	SEALING, Fr Panel	BU195-167X01	92086909	1	1
008	SEALING, B. Side	AU105-113	92063361	2	2
009	CONNECTOR, Cable	BU56-602-NX06	106-104-000	1	1
010	GASKET	AU105-113		1	1
100	GAS Control Assy	C36E-43-S	120-156-000	1	1
101	SCREW, Press Pt. SeaL	C10D-5	501-275-005	3	3
102	CONNECTION, Gas Inlet 3/4	CU195-211	106-290-000	1	1
103	BURNER UNIT Assy	H73-110X04	92092212	1	1
104	BURNER CASE, Fr. plate	CH51-209X04		1	1
105	BURNER CASE, Btm plate	H73-112X01		1	1
106	GASKET, Burner Case	BH51-218X01		1	1
107	BURNER, Assy	B3A-1X04		16	16
108	BURNER CASE, Back plt	CH51-221X04		1	1
109	DAMPER	H73-115	140-597-000	1	1
110	MANIFOLD Assy (LPG)	U245-200-A	101-559-000	1	1
110	MANIFOLD Assy (Nat G)	U245-200-B	101-560-000	1	1
111	SEALING, Comb	AU155-207-2		1	1
112	SEALING LOWER, Comb Cmbr	H73-214X01		1	1
114	FRONT PLATE, Comb Cmbr	U245-260		1	1
115	FRONT PLATE, Comb Cmbr	U245-261		1	1
116	ELECTRODE	H73-120	202-156-000	1	1
117	ELECTRODE FR	AH41-216	230-047-000	1	1
118	GASKET, Electrode Packing	AH66-393X01	580-507-000	1	1
119	HOLDER, Electrode	AH66-393	580-505-000	1	1
120	PACKING UPPER, Comb Cmbr	U245-262		1	1
121	JOINT, Back Press.	U242-312		1	1
122	TUBE - C, Wind Press.	AU161-665-CX01	92071570	1	1
125	FAN MOTOR Assy	U245-753	222-513-000	1	1
126	FAN CASING Assy	U245 -555		1	1
127	CONNECTION, Fan	BH29-606X08		1	1
128	PACKING, Fan Conn.	U245-750		1	1
129	FAN MOTOR	U245-753		1	1
130	BELL MOUTH	U245-558X01		1	1

No	Part Name	RJ Drawing No.	RUK Part No.	26i	HD50i
131	HOLDER, Joint	U245-566		1	1
135	DUCT, Air Intake	U245-401		1	1
136	HOLDER, Joint	U245-408		1	1
137	JOINT	U245-409		1	1
138	CLIP, Joint	U245-567		1	1
139	TERMINAL, Air Intake	U245-410-2		1	1
140	FRAME, Flue Collector	U245-434		1	1
141	HOLDER, Flue Collector	U245-435		2	2
142	LID, Air Intake Term	U245-419		1	1
145	CLOSURE, Heat Exch Assy.	U245-690	314-516-000	1	
145	CLOSURE, Heat Exch Assy	U245-690-C			1
400	CONNECTION 3/4, Inlet Water	H73-501X02	333-301-000	1	
401	SERVO, Water Flow and Assy	M8E-6-6	301-095-000	1	1
401	SERVO, Water Flow and Assy	M8E-6-7			
402	RECTIFIER	M8D1-15	330-107-000	1	1
403	SERVO Assy, Bypass	M6J-1-3	301-084-000	1	1
404	BRACKET	AH69-310		2	2
405	STRAP, Plug	H73-512X02		1	1
406	FILTER, Inlet Water Assy	H73-511	017-268-000	1	1
407	FILTER, Plug	H73-510	196-031-000	1	1
408	CONNECTION 3/4, Hot Water	U245-865-1	333-386-000	1	1
409	JOINT, Back Pressure	U245-401		1	1
410	BRACKET, Holder	AU162-1876X01		1	1
411	VALVE, Drain Assy	BU129-520-CX02	337-048-000	1	1
700	PCB Assy	U245-770	210-564-000	1	1
701	SUB BOARD, Assy	BU195-1643-2	210-565-000	1	1
702	COVER, PCB	U245-774		1	1
703	COVER, EC	BU168-707X01		1	1
704	TRANSFORMER Assy	ET-282	224-326-000	1	1
705	MOUNTING PLATE, PCB Case	U245-257		1	1
706	SPARKER	EI-189	261-153-000	1	1
707	LEAD, High Tension	BH38-710-240	203-828-000	1	1
708	SLEEVE, Electrode	AU206-218		1	1
709	THERMISTOR	BH45-650X01	233-108-000	2	2
710	HOLDING PLATE, Large	CP-90172		1	1
711	MOUNT BKT, Fuse	U217-676X02		5	5
712	SWITCH, Frost Sensor	U242-511	234-540-000	1	1
713	HEATER Assy, A/Frost	U245-775	235-308-000	1	1
714	HEATER, Valve	U245-776		1	1
716	MOUNTING BRACKET, Htr	CF29-742X01		2	2

No	Part Name	RJ Drawing No.	RUK Part No.	26i	HD50i
717	MOUNTING BRACKET, Htr A	AU111-6539209331911			
718	MOUNTING BRACKET, Htr	AU100-721X03		1	1
719	THERMISTER, Inlet Air	BH195-1630	233-198-000	1	1
720	POWER CORD	CP-90491T		1	1
721	HARNESS, Fuse	U245-603X02		1	1
722	HARNESS, 100V	U245-885		1	1
723	HARNESS, Solenoid Valve	U245-602		1	1
724	HARNESS, Sensor	U245-603X02		1	1
725	FUSE Assy, Thermal	U245-885920	232-153-000	1	1
726	MR SENSOR Assy	M8D1-10-4920	243-072-000	1	1
800	BOLT	ZIHD0510UK		8	8
801	SCREW, Small Truss	ZAD0408UK		3	3
801	SCREW, Small Truss	ZHDC0408TK		1	1
802	WASHER	AU33-184X01		3	3
803	SCREW	CP-21478-412X01		3	3
804	SCREW, Thermister	U217-449		1	1
805	SCREW, Small Pan	ZAA0408UK		3	3
810	O-RING	M10B-2-4	520-209-010	2	2
811	O-RING	M10B-2-3	520-046-010	1	1
812	O-RING	M10B-2-13-4	520-300-010	3	3
813	O-RING	M10B-2-18	520-049-010	2	2
814	O-RING	M10B-2-16	520-048-010	2	2
815	O-RING	M10B-2-14	520-193-010	2	2
816	O-RING	M10B-2-7	520-281-010	1	1
817	O-RING	M10B-1-24	520-043-010	1	1
818	WASHER	C36E1-6		2	2
888	CONVERSION KIT Nat. Gas		923L2130NG0	1	1
888	CONVERSION KIT LPG		923N2130LPG	1	1
889	INSTALLATION AND USER INSTR	U245-790		1	1

Notes

SERVICE CONTACT POINTS

Rinnai UK LTD.

9 Christleton Court
Manor Park
Runcorn
Cheshire
WA7 1ST

Tel. 01928 531870

Fax. 01928 531880

E-mail. info@rinnaiuk.com

Web. www.rinnaiuk.com